



Installation of a rear rigid element as **Pick Up**



1/ Install the joint on the window. Slip around the window a string.



2/ Before the installation of the window on the rigid element, put some rubber grease on the joint.



3/ Put the window from the outside towards the inner. Pull the string towards the centre of the window to put adjust the joint.



4/ Install the rigid roof.

Installation of a rear rigid element as Pick-Up



5/ For an easy marking and drilling of the elements, put a mark onto the hole axes on the vehicle.



6/ Fit the roof inside the pick up element which is fix for the lower part.



7/ Install the element lateral to the panel, put a mark for the drilling.



8/ Drill 5mm, then 10mm.



9/ Fix with the 9 x 35 th screws.



10/ Fix the sealing sleeve with the swivels.

Installation of a rear rigid element as Pick-Up



11/ Intercalate the upper part of the sleeve between the roof and the element.



12/ Insert the sleeve inside.



13

13/ Fix the sleeve on the element with the grey joint.



The installation of the pick-up set is finished.

CASSIS